



Outdoor Woodburning Fireplace Concrete Cement Patch Kit Instructions

1. Evaluate area needing to be patched. Note, intended use applies to minor chips and cracks. Not to be used as an adhesive or to repair broken cement pieces.
2. Clean damaged area of any dirt or debris.
3. Tear pouch containing cement powder.
4. Pour needed amount of powder into a disposable plastic mixing container.
5. Slowly add water to cement powder and stir until mixture solidifies into a paste.
6. Apply cement paste to the damaged area.
7. Allow 2 – 3 hours to dry.
8. Sand patched area, if desired.

For technical assistance, contact Customer Service: **888.493.8898**